




The BHF Cattle Oiler is designed for easy installation and flexible use. The height can be raised and lowered depending on the size of cattle.



'B' CATTLE OILER



'C' CATTLE OILER

For best results, hang the oiler so that the bottom is 3" below the back of the animal. As cattle walk underneath the felt it will tip the oiler and allow more oil to be released through a hole located at the center.

